



ELECTRICAL USAGE GUIDE

Use this guide to help estimate your electrical service needs. Please check the electrical label on your equipment for its exact amperage to guarantee there is enough power for your device.

Approximately 100 watts = 1 amp

DEVICE	AMPERAGE	NOTES
CREDIT CARD READER	1 amp	
CASH REGISTER/POINT OF SALES	1-2 amps	
CELL PHONE CHARGER	1-2 amps	
COFFEE POT	12-20 amps	1 circuit, dedicated outlet
COMPUTER MONITOR	1-2 amps	
HEAT LAMP (individual)	2.5 amps	
PORTABLE HEATER	20 amps	1 circuit, dedicated outlet
HOT PLATE	20 amps	1 circuit, dedicated outlet
INSULATED COOLER (standing)	6-10 amps	
INSULATED WARMER (standing)	20 amps	1 circuit, dedicated outlet
I-PAD CHARGER	1-2 amps	
LAPTOP CHARGER	2-3 amps	
LED STRIP LIGHTS	2 amps	
MICROWAVE (depends on size)	20 amps	1 circuit, dedicated outlet
POPCORN MAKER	20 amps	1 circuit, dedicated outlet
PROJECTOR (depends on size)	10 amps	
REFRIGERATOR (small)	1 amp	
REFRIGERATOR (large)	7 amps	
T-SHIRT PRESS	20 amps	1 circuit, dedicated outlet
TELEVISION MONITOR (depends on size)	5 amps	
TOASTER	10 amps	
VACUUM CLEANER	15 amps	1 circuit, dedicated outlet
WATER COOLER	1 amp	

Please read the item's electrical label if it is not listed.

Any combination of items at 15 amps or more will require an additional circuit.